

NTV44P

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Power supply NTV 44 Processing



Function:

The Power supply **NTV 44 Processing** was developed to use the L-Probe on all common controller systems. The new power supply converts the L-Probe Signal to an equivalent mV Signal of a Oxygen Probe. With the Terminal T300 the user can input the correction Factors K1,K2.

A two point correction mechanisms is included. Special functions as flushing Probe, recovery time and flushing time will be input via Terminal T300. The **NTV 44 Processing** supplies high constant voltages (e.g. at lambda probes and other loads).

An active 4-wire circuit ensures that line resistances up to 1 ohm and the related voltage drops are compensated.

The polarity of the heating voltage is reversed automatically at regular intervals to avoid effects of oxidation on the lambda probe heater which shorten the life of the probe.

Line cross sections:

Two-wire circuit: $\leq 2 \text{ m} \geq 1,00 \text{ mm}^2$

Four-wire circuit: $\leq 15 \text{ m} \geq 0,50 \text{ mm}^2$

$\leq 20 \text{ m} \geq 0,75 \text{ mm}^2$

$\leq 30 \text{ m} \geq 1,00 \text{ mm}^2$

$\leq 40 \text{ m} \geq 1,50 \text{ mm}^2$

$\leq 70 \text{ m} \geq 2,50 \text{ mm}^2$

Technical data

Construction:
Macrolon housing for wall mounting

Dimensions/ Weight:
160 x 120 x 90 mm (l x w x h) / 1,85 kg

Protection type:
Housing IP 64

Connection:
Pluggable screw terminals
Wire cross section: max. 2.5 mm

Connection L-probe:
1 m connection cable with plug and coupler

Cable feeds:
7 screw-type glands, PG7, PG9 and PG11

Auxiliary voltage:
115 / 230 Vac/50-60 Hz, approx. 50 VA

Input measuring probe:
0...1300 mVdc (L-probe signal)

Output power supply unit:
12.00 Vdc max. 3 A tol. +20 mV
(heating voltage for L-probe)

Output measuring probe:
0...1300 mVdc (L-probes-signal, 1:1)
Option: physically separated output
0...20 mA or 4...20 mA

Line resistance:
max. 1 ohm

Climate:
Storage: -10...+70 °C
Operation: 0...+50 °C
5...95 % relative humidity, non-condensing

Power supply NTV 44 Processing



Technical data (continued)

Basic (basic functions):

- Non-isolated voltage output 0...1.3 V
- Optional isolated universal output 0...10V or 0...(4)...20 mA
- Time-controlled probe purging function (optional)

Advanced (Advanced functions)

- %O2 and Dew Point calculation with current temperature (measured by thermocouple K or S type)
- Conversion of L-probe voltage into O2 sensor voltage
- Optional handheld terminal T300* for configuration of universal outputs, two point correction constants
- Digital input and two digital outputs
- Four modes for define flushing (Time, voltage, temperature, digital input)
- Current or voltage output of O2% in the range defined trough terminal T300*

Isolated analog output as standard in advanced version

Order number

520-4185
520-4187
520-4180
520-4188
520-4181
520-4182
520-4183
520-4186

Device name

Power supply NTV 44 P with housing
Power supply NTV 44 P without housing
Power supply NTV 44 P - Basic with housing
Power supply NTV 44 P - Basic without housing
Power supply NTV 44 P - Advanced %O2
Power supply NTV 44 P - Advanced TP
Power supply NTV 44 P - Advanced L/O2
Power supply NTV 44 P - Advanced Lambda

Optional accessories

530-2126

Terminal T 300 for NTV44P

*** Terminal T300 is an optional device for this article**

Language

1: German
2: English

Main-Menu:

1 Measurements
2 Errors, Reset
3 NTV Settings
4 Start Flushing
5 T300 Settings
6 NTV44 Version
7 Correction



По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93