

LV200

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

AIR SUPPLY UNIT LV 200



FUNCTION

The LV2 air supply unit is used for continuously supplying all common oxygen probes with reference air.

A defined volume of filtered external air is pressed into the inside of the zirconium oxide pipe. The low gauge pressure largely prevents any penetration of the furnace atmosphere into the zirconium oxide pipe.

The volume of reference air selected should not be too great otherwise there will be an unnecessary cooling of the built-in thermoelement. As a rule, oxygen probes with through zirconium oxide pipes (MESA oxygen probes) require almost no reference air so that the temperature measurement error is negligible in these probes.

In addition to the reference air the LV2 also offers an air output for the probe rinsing. This externally triggerable air output is used for rinsing out the space between the protective pipe and the zirconium oxide pipe.

This function is triggered automatically at certain times for a certain duration by state-of-the-art C- level controllers(MCON Carbo).The aim of this function is to remove soot particles and other contamination by burning off and rinsing out.

TECHNICAL DATA

Pump:	Diaphragm pressure pump End pressure +-20% — 2.8 (0.27) mWs (bar) Free yield — 168 l/h Built-in filter
Reference air:	Measuring range (adjustable with valve) 1.6 l/h to 16 l/h Accuracy class 2.5 VDI/VDE 3513, sht. 2 Readoff length 100 mm
Rinsing air:	Measuring range (adjustable with valve) 10 l/h to 100 l/h Accuracy class 2.5 VDI/VDE 3513, sht. 2 Readoff length 100 mm Built-in non-return valve
Measuring principle:	Floating body
Switch cabinet:	Wall housing, steel-plated RAL 7032 pebble grey Protection type IP 55 Cable and hose glands PG 13.5

Dimensions:	380 x 300 x 255 mm (WxHxD)
Air connections:	Hose nozzles for 4 mm I.D.
Electr. data:	Pump, solenoid valve — 230 V/50 Hz
Power consumption:	approx. 20 VA
Ambient temperature:	-10 to 50 degrees Celsius
Accessories:	Plastic hose: Internal diameter: 4 mm External diameter: 6 mm

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231	Казань (843)206-01-48	Новокузнецк (3843)20-46-81	Смоленск (4812)29-41-54
Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Новосибирск (383)227-86-73	Сочи (862)225-72-31
Астрахань (8512)99-46-04	Калуга (4842)92-23-67	Омск (3812)21-46-40	Ставрополь (8652)20-65-13
Барнаул (3852)73-04-60	Кемерово (3842)65-04-62	Орел (4862)44-53-42	Сургут (3462)77-98-35
Белгород (4722)40-23-64	Киров (8332)68-02-04	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Брянск (4832)59-03-52	Краснодар (861)203-40-90	Пенза (8412)22-31-16	Томск (3822)98-41-53
Владивосток (423)249-28-31	Красноярск (391)204-63-61	Пермь (342)205-81-47	Тула (4872)74-02-29
Волгоград (844)278-03-48	Курск (4712)77-13-04	Ростов-на-Дону (863)308-18-15	Тюмень (3452)66-21-18
Вологда (8172)26-41-59	Липецк (4742)52-20-81	Рязань (4912)46-61-64	Ульяновск (8422)24-23-59
Воронеж (473)204-51-73	Магнитогорск (3519)55-03-13	Самара (846)206-03-16	Уфа (347)229-48-12
Екатеринбург (343)384-55-89	Москва (495)268-04-70	Санкт-Петербург (812)309-46-40	Хабаровск (4212)92-98-04
Иваново (4932)77-34-06	Мурманск (8152)59-64-93	Саратов (845)249-38-78	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Набережные Челны (8552)20-53-41	Севастополь (8692)22-31-93	Череповец (8202)49-02-64
Иркутск (395)279-98-46	Нижний Новгород (831)429-08-12	Симферополь (3652)67-13-56	Ярославль (4852)69-52-93
Россия (495)268-04-70	Киргизия (996)312-96-26-47	Казахстан (7172)727-132	