

Carbo 47

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231	Казань (843)206-01-48	Новокузнецк (3843)20-46-81	Смоленск (4812)29-41-54
Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Новосибирск (383)227-86-73	Сочи (862)225-72-31
Астрахань (8512)99-46-04	Калуга (4842)92-23-67	Омск (3812)21-46-40	Ставрополь (8652)20-65-13
Барнаул (3852)73-04-60	Кемерово (3842)65-04-62	Орел (4862)44-53-42	Сургут (3462)77-98-35
Белгород (4722)40-23-64	Киров (8332)68-02-04	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Брянск (4832)59-03-52	Краснодар (861)203-40-90	Пенза (8412)22-31-16	Томск (3822)98-41-53
Владивосток (423)249-28-31	Красноярск (391)204-63-61	Пермь (342)205-81-47	Тула (4872)74-02-29
Волгоград (844)278-03-48	Курск (4712)77-13-04	Ростов-на-Дону (863)308-18-15	Тюмень (3452)66-21-18
Вологда (8172)26-41-59	Липецк (4742)52-20-81	Рязань (4912)46-61-64	Ульяновск (8422)24-23-59
Воронеж (473)204-51-73	Магнитогорск (3519)55-03-13	Самара (846)206-03-16	Уфа (347)229-48-12
Екатеринбург (343)384-55-89	Москва (495)268-04-70	Санкт-Петербург (812)309-46-40	Хабаровск (4212)92-98-04
Иваново (4932)77-34-06	Мурманск (8152)59-64-93	Саратов (845)249-38-78	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Набережные Челны (8552)20-53-41	Севастополь (8692)22-31-93	Череповец (8202)49-02-64
Иркутск (395)279-98-46	Нижний Новгород (831)429-08-12	Симферополь (3652)67-13-56	Ярославль (4852)69-52-93
Россия (495)268-04-70	Киргизия (996)312-96-26-47	Казахстан (7172)727-132	



Intelligent Transmitter Type: Carbo 47

Special features:

- Calculates C-level from the residual oxygen content of a gas or CO₂-content from the furnace atmosphere
- Converts the L-probe voltage to the voltage curve of a zirconium oxide probe
- Parameter input via plug-in terminal
- Menu-guided operation
- High operation per galvanic separation of all inputs
- Optional connection of two thermocouples Type "K" and "S"
- Additional input for CO-analyzer

Function:

The **Carbo 47** is an intelligent transmitter designed for connecting different types of sensors. The unit processes the input signals and outputs the desired output variable as a voltage or current unit signal.

The versions described here convert the residual oxygen content of a gas to other components such as C-level based on the assumed gas equilibrium.

Determination of the C-level in conjunction with a conventional controller enables a favourably priced system for controlling carbon atmospheres in heat treatment plants.

The system still contains the facilities offered by more expensive systems, such as actual value correction (see below). The investment is soon amortized even on smaller furnace systems.

Another practical function of the unit is the conversion of the L-probe voltage into the probe voltage of a conventional zirconium oxide probe (see the appropriate data sheet for the **L-probe**). This allows the cheaper, more robust L-probe to be adapted to existing control systems.

Overview of types:

Type	Input	Output
1:	L-probe, thermocouple Type "K" or "S"	0...1300mV ZrO ₂ -probe- charakteristik
2:	L-probe, thermocouple Type "K" or "S"	C-level (0...20 mA) (0...10 V)
3:	ZrO ₂ -, thermocouple Type "K" or "S"	C-level (0...20 mA) (0...10 V)
4:	CO ₂ -analyzer, thermocouple Type "K" or "S"	C-level (0...20 mA) (0...10 V)

C-level measurement (principle):

measured: Temperature Ref. pt temperature O ₂ content via ZrO ₂ or L-probe	output: C-level (0...20 mA)
---	---------------------------------------

Parameter (fixed value):

CO content
Correction data

Actual value correction:

To eliminate measuring errors and deviations due to special conditions in the furnace, a correction of the calculated C-level which is based on foil samples, is provided.

Technical Data (basic unit):

Housing:

Wall housing made of polystyrene

Dimensions:

296 x 256 x 118 mm (w x h x d)

Weight:

approx. 2 kg

Protection type:

IP 50 according to DIN 40050

Climate:

Storage: -10...+70 °C

Operation: 0...+50 °C

5...95 % relative humidity, non condensing

Auxiliary voltage:

115 / 230 Vac +- 10 % 50 - 60 Hz

Power consumption:

approx. 15 VA

Fuse:

230 V: 1 x 0,315 A slow blow

Analog inputs:

Type 1:

- thermocouple, Type "K" or "S"
- L-probe

Type 2:

- thermocouple, Type "K" or "S"
- L-probe
- CO-analyzer

Type 3:

- thermocouple, Type "K" or "S"
- ZrO₂-probe
- CO-analyzer

Type 4 :

- thermocouple, Type "K" or "S"
- CO₂-analyzer 0...3 % log. or 0...0.5 % lin.

Terminal Type: T-200 M

Analog outputs:

Type 1:

ZrO₂ - probe: 0...1300 mV -> 0...1300 mV

Type 2:

C-level: 0...1,5 %C -> 0...20 mA or
0...10 V

Temperature: 0...1200 °C -> 0...10 V

ZrO₂ - probe: 0...1300 mV -> 0...10 V

L-probe: 0...1300 mV -> 0...10 V

Type 3:

C-level: 0...1,5 %C -> 0...20 mA or
0...10 V

Temperature: 0...1200 °C -> 0...10 V

ZrO₂ - probe: 0...1300 mV -> 0...10 V

Type 4:

C-level: 0...1.5 %C -> 0...10 V or
0...20 mA

Temperature: 0...1200 °C -> 0...10 V

CO₂-Analysator:

0...3,0 % log.
or 0...0,5 % lin. -> 0...10 V

Digital output:

"open collector" max. 30 mA / 30 V

Display:

see input terminal T-200 M

Connections:

cable: 32 pin surrender connector
with screw connection

T-200 M: 2 x 9 pin D-Sub connector
on the Front panel

Housing:

Plastic

Dimensions:

91.5 x 146.3 x 32 mm (wxhxd)

Weight:

approx. 0,2 kg

Climate:

Storage : -10...+70 °C

Operation: 0...+50 °C

5...95 % relative humidity, non condensing

Display:

twolines Display (16-digit)
with lighting in the background

Character size:

5,6 x 3,0 mm (h x w)

Keyboard:

16 Keys

Connection:

2 x 9-pol. D-Sub connector (housing backside)

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93