

# Carbomat-M

## По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89  
Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Россия (495)268-04-70

Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Липецк (4742)52-20-81  
Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Пермь (342)205-81-47  
Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Симферополь (3652)67-13-56  
Казахстан (7172)727-132

Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Тверь (4822)63-31-35  
Томск (3822)98-41-53  
Тула (4872)74-02-29  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Ярославль (4852)69-52-93

## C Level Controller Type: Carbomat-M



### Special features:

- Menu-guided operation
- Foil keyboard
- Exact C level control
- Soot limit monitoring
- Universal application of optional connection of O<sub>2</sub>, O<sub>2</sub>+CO<sub>2</sub>, CO detectors and two thermocouples (type S or K)
- O<sub>2</sub> -probe monitoring (checking Ri and EMF, purging)
- Simultaneous measurement with two probes for super version
- Automatic change to spare probe
- Program memory with 99 set point programs for C level and temperature
- Analog output, for example, for recorder connection
- C level correction (for example, by means of foil specimens)
- Options:
  - Serial interface for example, for process visualized software "MESAVis"

### Function:

The **Carbomat-M** is a single-channel measuring and control system for C level calculation and control in the furnace atmosphere of heat treatment plants.

By means of switch settings on the rear panel of the instrument, **Carbomat-M** can be easily adapted to match existing facilities. Alterations in the data acquisition scheme, for example, change of gas analyzers to oxygen probes, can be effected without difficulty.

A currently available analytical method for determining the carbon content in furnace atmospheres is the indirect measurement of the oxygen content in the furnace with zirconium oxide probes. **Carbomat-M** provides special support for these methods. Datasheets on probes and other equipment are available on request.

## C Level Controller Type: Carbomat-M



### Technical Data:

#### Construction:

Metal housing for mounting in control panels, in conformance with DIN 40050  
Type of protection IP 54, as specified in DIN50050

#### Dimensions:

144 x 144 x 300 mm (l x w x h)

#### Auxiliary voltage:

230 Vac  $\pm$  10 % 50/60 Hz

#### Power consumption:

About 15 VA

#### Input signals (selected by means of switch setting):

##### Analog (in following combinations):

- O<sub>2</sub> measuring probe, cell voltage directly or through amplifier
- O<sub>2</sub> measuring probe and CO analyzer
- CO<sub>2</sub> analyzer
- CO<sub>2</sub> analyzer and CO analyzer
- O<sub>2</sub> probe and L-probe
- O<sub>2</sub> probe, L-probe and CO analyzer
- L - probe and CO analyzer
- L - probe and CO<sub>2</sub> analyzer
- L - probe, CO<sub>2</sub> analyzer and CO analyzer
- L - probe and L-probe
- O<sub>2</sub> probe and O<sub>2</sub> probe
- CO analyzer and O<sub>2</sub> probe

#### Attention:

If you use L-probe and O<sub>2</sub> - probe you can't connect an additional Reference junction.

- Thermocouple, type K or S
- Reference junction, type K or S (also mixed)
- Terminal temperature (Pt 100)
- External set value: analog or through **serial interface**

#### Digital:

- IN 0: program release with set point program in progress: otherwise, controller locked
- IN 1: program continuation in succession
- IN 2: input disable

#### Serial interface(option):

- RS 232
- RS 422 / RS 485
- 20 mA current loop (TTY)

#### Output signals:

##### Analog:

- C potential actual value, selected, 0 to 20 mA, 4 to 20 mA or 0 to 10 Vdc  
(in three scale divisions: 0...1,5 %; 0,15...1,5 %; 0...2,0 %)

**Option:** -Integrated temperature transmitter - 11 additional control tracks with an external box.

##### Switching outputs:

- 5 control tracks freely available
- 2 switching outputs for 1 motor valve for gas or solenoid valves for gas and air
- Signal gas release
- Signal probe purging
- Signal actual values in tolerance range
- Signal program active
- Signal Alarm indication

(all outputs "open collector" 24 V / 100 mA)

#### Display:

Graphical LCD display with 160 x 128 pixels

#### Operation:

Five keys (soft keys) with user guidance (menu guidance);  
respective function of the keys indicated on display

#### Set point:

- 4 preset points for C level
- 99 set point programs for C level profiles, internally storable and recallable;  
(program travel time per program: up to 100 h)
- 23 segments / program
- External entry by means of program generator, for example, 0...20 mA, 4...20 mA, 0...10 V.

#### Option:

- 99 set point programs for C level and temperature profiles
- Set point through serial interface

#### Climate:

Storage: -10...+60 °C  
Operation: 0...+50 °C  
5...95 % relative humidity, non-condensing  
**Impedance for cell voltage: > 100 MOhm**

**По вопросам продаж и поддержки обращайтесь:**

Алматы (7273)495-231  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89  
Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Россия (495)268-04-70

Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Липецк (4742)52-20-81  
Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Пермь (342)205-81-47  
Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Симферополь (3652)67-13-56  
Казахстан (7172)727-132

Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Тверь (4822)63-31-35  
Томск (3822)98-41-53  
Тула (4872)74-02-29  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Ярославль (4852)69-52-93